



Estimated Coverage Solvent Cement & Primer

How to work out how much solvent cement and primer is required

Tri Underground supply a range of solvent cements and primers to suit rigid PVC conduits. These are designed to join and clean conduits for non-pressure conduit applications. If you are unsure how much you require for your next project, please refer to the table of estimates below which is designed to work as a guide only. Real life applications may result in more or less material being used.

Conduit Size	Average number of joints per litre	
	Blue Solvent Cement	Red Priming Fluid
40	100	500
50	60	300
63	60	250
80	50	200
100	48	150
150	40	90
200	15	30



) 1300 874 874

sales@triunderground.com

QLD 46-56 Potassium Street, Narangba QLD, 4505

NSW Warehouse 3/2 Percival Road, Smithfield NSW 2164

www.triunderground.com

VIC Unit 2/12 Holcourt Road, Laverton North, Victoria 3026